

P/N 820-TCH0-L10

1) Power On/Off & Volume Control Knob

Turn this knob clockwise to switch on. The more you turn this knob clockwise, the bigger the audio sound grows,

2) Squelch Adjuster and DSS (Dynamic Squelch Tuning System)

DSS: Default. The squelch level of your transceiver is dynamically adjust to get the best receive condition.

Squelch Adjuster: Turn this knob clockwise to the max, Turn counter-clockwise until you hear background noise and then turn the knob to the opposite direction until the noise disappears.

Emergency Button

Press this button to go to emergency channel (9 or 19). To return to the previous operation mode, press EMG button again.

4) PTT Button

While pressing this button, you can transmit. The Red LED lights during the PTT press.

5) Backlighting & Scan Button

Short press to change backlighting color (Red / Green / Amber / Off)

Long press to activate/deactivate channel scan. While scanning, press Up/Down button to change scanning direction.

6) Menu / Lock Button

Short press to access menu mode. Use the Up/Down button to change the setting. Long press to activate/deactivate keypad lock function.

<MENU>

< WIENU >					
Display	Functions	Settings			
Band		See next band chart			
Power		FM : High and Low AM : Low only			
Roger Beep Tone		On and Off			
6 P	Key Beep Tone	On and Off			
VOX		Off, Low, Middle, High			

Our Thanks to You

Thank you for purchasing a TTI CB TRANSCEIVER radio. Properly used this TTI product will give you many years of reliable service.

All our products are built to offer excellent value by combining advanced features, great design and manufacturing quality.

To ensure you are familiar with the operation and features of your radio, and in order to obtain the best performance, please read this manual carefully before operation.

1. Supplied Accessories

Package contents:

TCB-H100 transceiver Adapter with Antenna connector and cigarette lighter plug Belt clip



Note: The accessory package that includes a desk charger with power adapter, 2600mAh rechargeable battery, 17 cm antenna and belt clip can be purchased separately.

<BAND Chart>

Setting	Display	Settings
EC	EC	Europe 40ch. FM 4W
EU	Eu	Europe 40ch, AM/FM 4W
D	d	Germany 80ch. FM 4W, 40ch. AM 4W
12	15	Italy 34ch. AM/FM 4W
3		Italy 40ch, AM/FM 4W
UE(EU/UK)	UE	UK 40ch. FM 4W (British Frequencies) + CEPT 40ch. FM 4W(EC)
UK	ЦH	UK 40ch. FM 4W (British Frequencies)
PL	PL	Poland 40ch. AM/FM 4W (Polish Frequencies : 5KHz)
F	F	France 40ch. FM 4W, 40ch AM 4W
E	E	Spain 40ch, AM/FM 4W

7) Channel Up/Down Button Short press to change channel. Long press to speed up channel change.

8) Echo & AM/FM Button Short press to activate/deactivate Echo TX sound. Long press to switch AM/FM mode

9) Signal Strength Meter (S-RF)
Low transmitting power shows four S-RF meters.
High transmitting power shows full eight S-RF meters.
While receiving signal, actual reception signal strength is on display.


10) Low Batter Alert

In case Low battery, LED and battery indicator are blinking with alert sound for every 15 seconds.

2. Fitting the Battery Pack / Battery Eliminator

> Fittina

Ensure that your radio is switched off. Align the battery pack with the battery guide and Slide the battery pack up to the top until you hear the snapping sound.



> Removal

Ensure that your radio is switched off. Press down on the battery release catch and separate the battery pack from the radio.



3. Battery Charging

- 1) Connect the power adaptor to the main power supply and connect the adaptor charger jack to the charging cradle.
- 2) Disconnect any radio accessories and ensure the radio is switched off,
- 3) Insert the radio into the charging cradle until it clicks home. The charger LED will glow red and charging will start. If the charger LED blinks red or green or the charger LED does not light, re-insert the radio into the charging cradle.
- 4) The battery charging time is about 4-5 hours. When the battery is fully charged the charger LED will turn green.

Power Adaptor

- Input: 230VAC
- Output : 12VDC 1Ah

Vote:

- Upon the red LED blinking, there is a doubt on the battery quality.
- Upon the orange LED blinking, there is a doubt on the high temperature of the battery. In this case, separate the battery from the cradle and try again after cooling,

5. Trouble Shooting

If you experience problems with your TCB-H100, first check the battery power level or connection of battery eliminator as low batteries can cause problems such as poor transmission, weak reception and reduced sound quality. Then check the manual and radio display to ensure that a function (such as VOX or Lock) has not been activated by accident.

- 1) Switch off the transceiver.
- 2) Press and hold PTT button and Backlighting button, switch on the transceiver.
- 3) Wait for a while until reset display appears.

All the memories are erased by this reset and the parameters return to the initial factory setting. In case of further difficulty, please consult your dealer or visit our website at www.ttikorea.co.kr.

6. Safety Requirement

For charging the rechargeable battery, only a CE approved AC adaptor complying with the following specifications must be used.

INPUT: 230VAC 50Hz OUTPUT: 12VDC 1Ah

For direct operation by battery eliminator, following cigar adaptor must be used.

INPUT: 12/24VDC OUTPUT: 12VDC 3Ah

4. Transceiver Controls, Display and Functions Squelch Adjuster & DSS Knob Power & Volume Control Knob Antenna TX / RX / Low battery alert LED **Emergency Button** PTT Button Accessory Jack Speaker Backlighting (Short press) Scan Button (Long press) Display Menu (Short press) [P2] P3 PA Echo (Short press) Lock (Long press) AM/FM (Long press) Roger Beep Emergency Scan Echo Channel Lock DSS Battery Indicator External Accessory

AM Mode

Low Power

FM Mode

7. Specifications

Signal Strength Meter

GENERAL	Channel	40 (See the frequency band chart)
	Frequency Range	26.56 MHz ~ 28 MHz
	Operating mode	F3E (FM), A3E (AM)
	Frequency Control	PLL Synthersizer
	Frequency Tolerance	0.002%
	Operating Temperature Range	-10 to +55°C
	Power Supply	7.4V (Li-lon Battery) 12/24VDC (Battery Eliminator)
	Size	57 (W) x 116 (H) x 39 (D)
	Weight	224 grams with Battery pack
	Antenna Connector	SMA type
TRANSE	Power Output	Duty cycle 10% 4 Watts @ 13.2V DC
	Modulation	AM: from 85% to 95% FM: 1.8KHz ± 0.2KHz
M	Frequency Response	300Hz to 3000Hz
Ŧ	Output Impedance	50ohms, Unbalanced
TTER	Harmonic Suppression	Less than -54dBm
	Current Drain	AM Full Mod. 1.6A Max.
	Receiving System	Dual conversion superhterodyne
	IF Frequencies	Double conversion 1st 10.695MHz/2nd 455KHz
R	Sensitivity	$1.4\mu V$ for 10 dB(S+N)/N in AM Mode $0.8\mu V$ for 20dB SINAD in FM Mode
	Audio Output Power	1W @ 16ohm
Č	Audio Distortion	Less than 8% @ 1KHz
Ē	Image Rejection	More than 60dB
RECE-VER	Adjacent Channel Rejection	More than 60dB
	Conducted Spurious	Less than -57dBm
	Frequency Response	300Hz to 2500Hz
	Built-in Speaker	16ohms, Round
	Squelch	Adjustable; Threshold less than 1 µV DSS; Less than 2 µV

^{*} Specification is subject to change without prior notice,

10. Restrictions on the use

Country		Band	Use restrictions and other comments
BELGIUM	EU	F	EC 40 Ch - 4W FM - Individual licence is required
SWITZERLAND	EU	i ka	40 Ch - 4W AM - Individual licence is required
DENMARK,NORWAY LUXEMBOURG,CZECH			EC 40 Ch - 4W FM - Free use
FINLAND,PORTUGAL	EU	F	EC 40 Ch - 4W FM - Free use
FRANCE,NETHERLANDS	60		40 Ch - 4W AM - Free use
GERMANY	D		80 Ch - 4W FM - Individual licence is required
			40 Ch - 4W AM - Individual licence is required
	EU		40 Ch - 4W AM - Use ch 4-15 only
	D2		EC 40 Ch - 4W FM - Free use
	02		12 Ch - 4W AM - Individual licence is required
	fx Allowed: from 26.960 to 27.410 MHz "BAPT 222 ZV 104"		
GREECE	EU	F 7	EC 40 Ch - 4W FM - Free use
	EU	10.00	40 Ch - 4W AM - Free use
	T/R 20-02		
IRELAND	EU		EC 40 Ch - 4W FM - Free use
	EU	850	40 Ch - 4W AM - Free use
			WIRELESS TELEGRAPHY ACT, 1926 (SECTIONS) ZENS' BAND (CB) RADIOS) ORDER, 1998
ITALY	EU		EC 40 Ch - 4W FM - General authorization is required
	EU EU	-	40 Ch - 4W AM - General authorization is required
		100	34 Ch - 4W FM
		12	34 Ch - 4W AM(ERP) *AM mode allowed on ch1-23 or
	PNF issue	ed on DM 0	B.07.02 NOTES 49 A-B-C-D-E-G
SPAIN	- I		EC 40 Ch - 4W FM - Individual licence is required
	EU	OF-	40 Ch - 4W FM - Individual licence is required
	Art. 57 - Law 11/1998 dated 24th April		
SWEDEN			EC 40 Ch - 4W FM - Free use
	EU		40 Ch - 4W AM - Individual licence is required
UK	108		EC 40 Ch - 4W FM - Free use
	EU		40 Ch - 4W AM - Free use
POLAND	EU EU		EC 40 Ch - 4W FM / AM - Free use

<< Declaration of Conformity >>

We, TTI Tech Co., Ltd.: (B-912, Indeokwon IT Valley, 40 Irni-ro, Uiwang-si, Gyeonggi-do, Korea) declare on our sole responsibility that this equipment complies with the essential requirements of the Radio Equipment Directive (RED) 2014/53/EU, and that any applicable Essential Test Suite measurements have been performed.

Kind of equipment: HANDHELD CB TRANSCEIVER

Type-designation: TCB-H100

Version (where applicable)

This complicance is based on conformity with the following standards, specifications or documents:

EN 62311:2008	
EN 300 433	V2,1.1
EN 301 489-1	V2.2.0
EN 301 489-13	V1.2.1
EN 60950-1:2006+A11:2009	+A1:2010+A12:2011+A2:2013

N. Y. Kim Director (6

Korea, Dec. 31, 2019

Signature